Rubena



BELLOW TYPE


180x2

PRODUCT LINE

Rubena design line


COVER TYPE

Steel standard



| HEIGHT | | | STROKE | DIAMETERS | |
|--------|-------|------|--------|-----------|----------------|
| Hmax | Hstat | Hmin | L | ø Max | ø For assembly |
| [mm] | [mm] | [mm] | [mm] | [mm] | [mm] |
| 230 | 155 | 80 | 150 | 190 | 205 |

The data presented on this document are liable to change and do not constitute a commitment from Rubena, s.r.o.



| | | Application temperatures | | |
|--|---|--------------------------|-------------------|--|
| Rubber Type | Features | Static [°C] | Dynamic [°C] | |
| SBR | Standard use | -50° to 70° | -40° to 60° | |
| CIIR | For higher temperature, steam and acids* resistence | -30° to 90° | -20° to 80° | |
| ECO/GECO | Extreme heat endurance, best acids, oil and fuel resistence | -30° to 115° | -20° to 105° | |
| CR For higher temperature applications, acids an oil* resistance | | -35° to 90° | -25° to 80° | |
| CR (AF - Anti Fire) | For higher temperature applications, acids and oil* resistance; flame retardant, compatible with EN 45545 | -50° to 90° | -40° to 80° | |

^{*}depends on the type of acid / oil and their concentration. Always consult Rubena for specific use and application of the rubber type.

- 1) Airsprings must not be pressurised unless they are restricted by an outside frame or by a suitable load.
- 2) Strokes must be limited by the direct use of bump stops or external stops. When stacking airsprings, special cares must be taken to ensure the airsprings are guided and fixed
- 3) An Airspring is a single acting air actuator and must not be used below atmospheric pressure.
- 4) Please check the overpressure in case of quick compression.

The data presented on this document are liable to change and do not constitute a commitment from Rubena, s.r.o.